

1212/4 SLIDE-IN SYSTEM – STANDARD EVAPORATOR

INSTALLATION INSTRUCTIONS

1. It is essential that there is good ventilation above and around the unit to ensure efficient operation.
2. Cut a hole in the wall of the coolroom as shown on the sketch.
3. Fit the rubber seal around the edge of the prepared hole in the wall of the coolroom, for the flange of the unit to seal against.
4. Insert the unit through the hole from outside, and bolt in place and then fasten rear of evaporator cooler to internal roof of coolroom with bolts or screws.
5. Push the drain fitting into the rubber connection at the back of the drip tray to enable a drain hose to be connected, (some dishwashing liquid may facilitate this).
6. The drain tube should either be dropped into a container inside or outside the room, with the end under the water level at all times. If a container is not used, the a “P” trap should be fitted or formed at the lowest part of the drain tube to prevent air being drawn up through the tube which will affect both the flow of condensate from the evaporator tray, and system efficiency.
7. Connect to a dedicated 3 pin single phase 15 amp power point, the use of an extension lead is not acceptable.

This pack includes:

- 1 x Rubber Seal
- 1 x Drain Fitting

PLAN VIEW OF COOLROOM

