


## SLIDE-IN SYSTEM – MODEL 1300 LOW TEMP

### INSTALLATION INSTRUCTIONS

1. It is essential that there is good ventilation above and around the unit to ensure efficient operation.
2. Cut a hole in the wall of the coolroom as shown on the sketch.
3. Fit the rubber seal around the edge of the prepared hole in the wall of the coolroom, for the flange of the unit to seal against.
4. Insert the unit through the hole from outside, and bolt in place and then fasten rear of evaporator cooler to internal roof of coolroom with bolts or screws.
5. The drain tube should be dropped into a container outside the room, with the end under the water level at all times. If a container is not used, the a “P” trap should be fitted or formed at the lowest part of the drain tube to prevent air being drawn up through the tube which will affect both the flow of condensate from the evaporator tray and system efficiency.
6. Connect to a dedicated 3 pin single phase power point, the use of an extension lead is not acceptable.
7. A drain line heater cable is recommended for this model.

This pack includes:

1 x Rubber Seal



POSITION SLIDE-IN UNIT  
WITH FAN AT THE FRONT  
INSIDE THE COLDROOM.

### SIDE VIEW OF COLDROOM