

SLIDE-IN SYSTEM - STANDARD EVAPORATOR MODELS

2012/4 Slide-In

INSTALLATION INSTRUCTIONS

1. It is essential that there is good ventilation above and around the coolroom to ensure efficient operation.
2. Cut a hole in the wall of the coolroom as shown on the sketch (510mm x 1235mm).
3. Fit the foam seal around the edge of the prepared hole in the wall of the coolroom, for the flange of the unit to seal against.
4. Insert the unit through the hole from outside, and bolt in place, then fasten rear of evaporator cooler to internal roof of coolroom with bolts or screws, see fig 1.
5. Screw on a drain fitting into the underside of the driptray to enable a drain pipe to be connected.
6. The drain pipe should either be dropped into a container inside or outside the room, with the end under the water level at all times. If a container is not used, the a “P” trap should be fitted or formed at the lowest part of the drain tube to prevent air being drawn up through the tube which will affect both the flow of condensate from the evaporator tray, and system efficiency
7. Connect to a dedicated 15 amp, 3 pin, single phase power point. **The use of an extension lead is not acceptable.**

This pack includes:

1 x Rubber Seal




Fig 1.

